



Cable set CAB-2010



PC mic input cable



PC line input cable




PC line output cable



Ground Strap

PC mic input cable details:



For a typical PC microphone input, this cable allows you to make 2 measurements at once. Connect the XLR female to the generator output to inject low-level audio into the mic input. Connect the XLR male to the analyzer input (with DC coupling enabled) to measure the bias voltage.